IGT GL20

OPEN MAIN DOOR

Step 1: Turn audit key to disable alarm.

Step 2: Insert key into main door lock and turn key counter clockwise.

Step 3: Lift up on main door latch and hold door firmly as it automatically

OPEN BELLY DOOR

Step 1: Pull silver belly door handle up and toward you.

Step 2: Door opens to the left.

POWER RESET TERMINAL

Step 1: Open main door.

Step 2: Locate power switch above the bill validator. Turn switch to OFF (O) position. Leave the terminal down for at least 30 seconds before turning ON (–).

CLEAR BILL VALIDATOR JAM

Step 1: Pull down on green rectangular lever under the push button, pull forward to remove bill validator unit.

Step 2: Remove jammed bills/debris from both compartments of bill validator:

- To open front door, squeeze 2 green tabs together, lift up.
- To open back door, press green button, lift up.

Step 3: Ensure lenses are clean, if not, wipe with slightly damp cloth.

Step 5: Secure unit back in place. Make sure bill validator initializes.







POWER SWITCH











IGT GL20

REMOVE CASH BOX

Step 1: Open belly door.

Step 2: Unlock cash box panel door.

Step 3: Pull on cash box handle to remove cash box.

Step 4: Unlock cash box lock by inserting coin/back of key.

Step 5: Check for jams or empty.

Step 6: Close cash box door and lock by turning slot in horizontal position.

Step 7: Make sure bill validator initializes when inserted.

LOAD PAPER

Step 1: Load paper ticket stack in tray with print and clock mark facing up. A green light indicates paper is loaded correctly. Printer may be pulled forward to access.

Step 2: Feed ticket into printer mechanism until resistance is felt. Printer will automatically pull ticket in and align.

CLEAR PRINTER JAM

Step 1: Pull paper tray forward to access printer.

Step 2: Push black button back to open printer head.



Step 3: Pull yellow lever on right hand side down to release tension on paper guide. Remove paper jam.

Step 4: Reload paper and slide printer back in place.















IGT GL20

LAST TICKET REPRINT

Step 1: Turn audit key and open main door.

Step 2: Select [SUPPORT].

Step 3: Select [LAST VOUCHER REPRINT].

Step 4: Select [PRINT LAST VOUCHER] to reprint last cash out ticket.



TOUCH SCREEN CALIBRATION

Step 1: Turn audit key 3 times.

Step 2: Follow directions on screen.



OUT OF SERVICE

Step 1: Turn audit key.

Step 2: Select [OUT OF SERVICE] to disable the terminal until a technician arrives.



