SPIELO PRODIGI VU

OPEN MAIN DOOR

Step 1: Turn audit key to disable alarm.

Step 2: Insert key into main door lock and turn.

Step 3: Lift up on latch and open door. Door opens to the left.

POWER RESET TERMINAL

Step 1: Open main door.

bill

Step 2: Locate power switch to left of bill validator.

Step 3: Turn switch to OFF (O) position, leave power off for 30 seconds and then turn to ON (I) position.

CLEAR BILL VALIDATOR JAM

Step 1: Pull up on silver release lever at base of validator unit and remove.

Step 2: Open validator unit from top by sliding yellow cover forward, and pull up.

Step 3: Remove debris and ensure lenses are clean, if not, wipe with slightly damp cloth. Secure unit back in place. Make sure bill validator initializes.

REMOVE CASH BOX

Step 1: Unlock cash box panel door.

Step 2: Pull on cash box handle to remove cash box.



Step 3: Unlock cash box lock by inserting coin/back of key, check for jams or empty.

Step 4: Close cash box door and lock by turning slot in horizontal position.

Step 5: Make sure bill validator initializes when cash box is inserted.





POWER SWITCH



VALIDATOR UNIT







Customer Care Center 1-800-561-4770

SPIELO PRODIGI VU

LOAD PAPER

Step 1: Load paper ticket stack in tray with print and clock mark facing up. Printer will beep if not loaded correctly. Printer may be pulled forward a few inches for access.

Step 2: Feed ticket into printer mechanism until resistance is felt.

Step 3: Printer will automatically pull ticket in and align.



TICKET CLOCK MARK

CLEAR PRINTER JAM

Step 1: Slide paper tray forward a few inches to access printer.

Step 2: Slide yellow release lever toward you and lift out blue paper guide.

Step 3: Place thumb on indent and push firmly down to remove printer roller.

Step 4: Remove paper jam, insert printer roller and paper guide.

Step 5: Reload paper and slide printer back in.

LAST TICKET REPRINT

Step 1: Turn audit key.

Step 2: Open main door.

Step 3: Press [HISTORY].

Step 4: Press [TICKETS OUT]. Press [PRINT LAST CASHOUT] situated bottom of screen.



RELEASE LEVER





PRINTER ROLLER



SPIELO PRODIGI VU

TOUCH SCREEN CALIBRATION

Step 1: Turn audit key.

Step 2: Choose illuminated button on button panel or calibrate touch screen icon on main screen.



Step 3: Calibrate touch screen message will display.

Step 4: Touch plus symbol (+) and hold for a few seconds. Repeat each time it moves to a new location on the screen.

Step 5: When calibration is complete, an exit button will display.

Step 6: Select [EXIT] button to return to main screen.



whing Machine Accounting History Test OpSons Corrent

of screen to tes

DISABLE TERMINAL

Step 1: Turn audit key.

Step 2: Press [OUT OF SERVICE] and a checkmark will appear. This feature will disable the terminal until a technician arrives.



Automa Laval I		© 2011, Spialo International				Turn key to sell operator menu		
Gaming Machine	Accounting	History	Test	Options	Comm	Lune .	sit .	
an trainiformen to	at her bes	a Cartyred						
Gaming Machine Informat	don .							
Acted # Devial # Devis Devis Theory		NCT CONFIL NUT CONFIL Nut 22, 330 (11433-27	118.85 10.885 12				1	4
Firmente Tedelona 1700 Travision Roll Tellodore Firmentey Code Stantes		0a-1.13 (0 201 (1,1,1)) (2120(10)) (1,10)(1,0) (1,10)(1,0) (1,10)(1,0) (1,0)(1,0) (1,0)(1,0) (1,0)(1,0) (1,0)(1,0) (1,0)(1,0)(1,0) (1,0)(1,0)(1,0) (1,0)(1,0)(1,0)(1,0) (1,0)(1,0)(1,0)(1,0) (1,0)(1,0)(1,0)(1,0)(1,0) (1,0)(1,0)(1,0)(1,0)(1,0)(1,0)(1,0)(1,0)	inimitan ini-iti, iti itin a netta 7	é li OLINA Reflecti, OR	(Distan	10494-646		
Conjecture Narrasva Electronium Narobet Concores adotace 1905-03,1 2012,298000, 0000 Cone,208000, Narobet Narobet Statuse Narobet 2000 2000 2000 2000 2000 2000 2000 20	86.1.8	2.4.194.4 2.4.172.9 2.4.122.9 2.410.2.9 2.401.2.9 2.401.2.9 2.103.	Presso Presso Presso Checker Checker Checker Checker Checker Checker	484 1981 1991 1941 1944			ħ	



